



LiComPerl

**DEVELOPMENT OF COMPOSITE LIGHTWEIGHT MATERIALS WITH UPGRADED
PHYSICOCHEMICAL FUNCTIONALITY AND IMPROVED ECONOMIC FEASIBILITY**

PI Annual Meeting Oct. 9th – 13th 2022



Perlite Institute
Associate member

Project's Scope (I)

Acquire know-how on the development of composite lightweight materials, which can be applied to a variety of materials and applications:

- ▶ Perlite substrates of different particle size distributions (coarse, medium, fine, ultrafine expanded grains) expanded at different conditions
- ▶ Multi-functional materials of various physicochemical characteristics as coatings, e.g. inorganic and/or organic, photocatalytic, nano-materials
- ▶ Different preparation techniques: coating and/or impregnation



VTCA based on optimization of physicochemical functionality and therefore economics.

Project's Scope (II)

Applications:

- ▶ **Construction: lightweight & insulation**
 - ▶ Functional material: Aerogel, PCMs
 - ▶ Perlite grades: fine, medium, coarse
- ▶ **Environmental: Photocatalysis, oil & dye removal, water treatment (heavy elements)**
 - ▶ Functional material: nano- TiO_2 & ZnO , alginate, emulsifiers, chitosan
 - ▶ Perlite grades: medium, coarse, fine, ultra fines
- ▶ **Agriculture: hydroponics, soil beneficiation**
 - ▶ Functional materials: zeolite, nutrients
 - ▶ Perlite grades: coarse, medium

Project's Scope (II)

Applications:

- ▶ **Construction: lightweight & insulation**
 - ▶ Functional material: Aerogel, **PCMs**
 - ▶ Perlite grades: fine, medium, coarse
- ▶ **Environmental: Photocatalysis, oil & dye removal, water treatment (heavy elements)**
 - ▶ Functional material: **nano- TiO₂** & ZnO, alginate, emulsifiers, **chitosan**
 - ▶ Perlite grades: medium, coarse, fine, ultra fines
- ▶ **Agriculture: hydroponics, soil beneficiation**
 - ▶ Functional materials: zeolite, nutrients
 - ▶ Perlite grades: coarse, medium

Application: Phase Change Materials (I)

➤ Materials

- Paraffins RT21 & RT31
- Expanded Perlite grades

➤ PCMs preparation

- Impregnation
- Different %loading 30 – 70%w/w

➤ Leakage Test




- Temperature: 25°C & 40°C
- Time: 4h

Grade / Code	LBD (Kg/m ³)
Fine Grade 0.3/0.075 PE-20012/3	50
	70
	90
Medium Grade 1.2/0.5 PE-20012/2	110
	130
	170






Application: Phase Change Materials (II)

Leakage Tests of Fine Grades



Leakage Tests of Medium Grades



Application: Phase Change Materials (III)

Conclusions


- Fine grades
 - Excellent behaviour without the need of external hydrophobation.
 - Leakage < 5% for loadings up to 70% w/w
- Medium grades
 - Moderate to bad behaviour
 - Leakage < 5% for loading up to 40%

Future Work


- Thermal Behaviour in plasters / mortars
 - Fine grades 50 – 70% impregnation loading

Application: Photocatalysis (I)

Step 1: Expansion of ultra-fine perlite grades



PE-20012/4-20



PE-20012/6-10

Code	LBD	Compressibility	Oil Absorption		Skeletal Density
	(kg/m ³)	(%)	(g oil/g perlite)	(g oil/100cc perlite)	(kg/m ³)
ULTRA FINE					
PE-20012/4-20	216	34.6%	1.17	25.7	1214.2
PE-20012/6-10	242	30.9%	0.94	22.7	1237.4

Step 2: Synthesis of TiO₂ nanospheres





Fig. 1 Image of the TiO₂ nanoparticles obtained by TEM

Step 3: Synthesis of EP@TiO₂ photocatalyst





Fig. 2 Image of the EP@TiO₂ photocatalyst obtained by SEM

Application: Photocatalysis (II)




Fig. 4 Time-dependent UV-vis spectra for the reduction of 4-nitrophenol by NaBH_4 in the presence of EP




Fig. 5 Time-dependent UV-vis spectra for the reduction of 4-nitrophenol by NaBH_4 in the presence of EP@TiO_2 photocatalyst during first and second catalytic cycle

Conclusions

- Adsorption of 4-nitrophenol on the porous substrate - Degradation of the pollutant
- Complete adsorption/degradation within 70 min.
- Reusable photocatalyst (48% reduction within 2h during a 2nd cycle).

Future Work

- Production of photocatalysts with other nanomaterials, like ZnO etc.
- Preparation of photocatalytic renders
- Investigation of in-doors behavior (formaldehyde degradation)

Acknowledgement

This work was done in the School of Mining and Metallurgical Engineering, National Technical University of Athens, which act as our subcontractor

Application: Heavy Elements Removal (I)

➤ **Materials**

- Expanded Perlite grades
- Chitosan (high molecular weight)

➤ **Composite materials' preparation**

- Up to 50% Chitosan

Grades	LBD (Kg/m ³)
Ultrafines	225
	257
Fines	90
	120
	140
Medium	110
	170



Ultrafines/50%Chitosan w/w



Fines90/50%Chitosan w/w






Medium110/50%Chitosan w/w

Application: Heavy Elements Removal (II)

- Heavy elements removal
 - Solution: 50 ppm Cu, 50 ppm Ni και 50 ppm Co
 - On-going

50% active material
in the specimens



Application: Heavy Elements Removal (II)

➤ Conclusions up to date

- Excellent behavior as far as % active material is concerned
- Floatable – Easy to handle


➤ Future Work

- Finalize optimum conditions
- Upgrade TRL to filters for wastewater treatment

After Test



Medium/50%Chitosan w/w



Ultrafines/50%Chitosan w/w

Acknowledgements

- ▶ The project is funded by the Greek Ministry of Development and Investments within the Action “Research – Create – Innovate” of the platform NSRF PARTNERSHIP AGREEMENT 2014-2020 originating from the European Structural and Investment Funds (ESIF) of the European Union.
- ▶ In.mat-Lab would like to thank also Sunrise Resources & Patrick Cheetham for the provision of the raw perlite samples and the fruitful collaboration



Perlite Institute Associate member



Member of the National Startup Registry



Member of the Hellenic Federation of Enterprises SEV –Scale Up



Thank you for your attention



Innovative Insulating & Inorganic Materials Laboratory

Lavrion Technological & Cultural park, P.O. Box 504, 195 00, Lavrion, Greece

T: +30 2292 300659, M: +30 69747538 & +30 6977692680

e-mail: info@in-mat-lab.eu

Website: www.in-mat-lab.eu

You can also follow us in LinkedIn: <https://www.linkedin.com/company/in-mat-lab>

